



MITSUBISHI SHOGUN LWB 2000-2017

PATT REF: H0259

- Our packing requirements
- BOOTLINER**
Minimum of 17 self-adhesive loop fastener tabs
1 x our ref 106 sewn hook/loop fastener tab
- REAR DOOR COVER**
Minimum of 25 self-adhesive loop fastener tabs



IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone.

Before applying any self-adhesive fastener pads, the surface MUST be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone) We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: The adhesive takes 24hrs to reach full adhesion – do not disturb during this time. In cold weather we advise you fit the liner in a warm environment (i.e. run the car till the interior is warm)

Preparation

- Remove the load space cover cassette

FITTING

BASE PANEL

- Position the base of the liner snugly into place. The hook fasteners will attach directly to the carpet.
- There are three hook fastener tabs sewn into the seam at the front of the base panel. Place them facing forward: They will attach directly to the carpet.

FRONT PANEL

- Pass the hook & loop fastener straps around the headrest posts and fasten close to the liner.
- Photo A: Pass the large two elastic loops around the second row seat upper outer wings.

SIDE PANELS

- Position the side panels snugly into place.
- Use the self-adhesive loop fasteners to attach the liner to the plastic panels.
- Photo B: The two small elastic loops to the front of the side panels attach to the seat belt tidy.
- Photo C: With the aid of a thin screwdriver or similar, thread the sewn hook/loop fastener tab through the vent.
- Photo D: Fasteners close the tab through the liner slots.

OPTIONAL EXTRAS

Rear Plus version liners – you will need to unfasten the headrest straps and elastic loops before you attempt to fold your 2nd row seats up!

Rear Door Cover: Use the self-adhesive loop fasteners supplied to attach the sides to the plastic panels.