

NISSAN X-TRAIL

2002-2007

Our ref: Ho282

Please note: This liner has been designed to be used with the 2nd row seat uppers in the middle locking position. (i.e.: 3rd out of 5 locking position)



Please note: these photos show a Rear Plus version Boot liner prepared for a Bumper flap

Packing requirements

BOOTLINER



BASE TABS



BASE TABS

2 own base tabs + 4 own base tabs
Minimum of 22 self-adhesive loop fastener pads

TAILGATE COVER

Minimum of 14 self-adhesive loop fastener pads

IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fasteners pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone) We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth. **NOTE:** The adhesive takes 24hrs to reach full adhesion – do not disturb during this time. In cold weather we advise you fit the liner in a warm environment (i.e. run the car till the interior is warm)

FITTING

- Remove load cover cassette, it can be replaced later.
- Place liner into car and unfold
- Position base of liner into place.
- **BASE**

At seat end: Attach ties to luggage retainers in floor panel. (Do not tie too tightly)

At tailgate end: On the base of the liner at the tailgate end, there are six hook fastener welds. Select the two similar hook/fastener tabs supplied separately: attach self-adhesive loop fastener pads to their hook fastener parts. Then attach to the two outer most welds on the liner base. Select the remaining four identical hook/loop fastener tabs: attach self adhesive pads to the hook fastener. Then attach to the remaining hook welds on the liner base. Lift central section of floor with liner. Wrap the protruding tabs around and under this floor panel remove fastener backing and stick. Replace the floor and liner. Repeat with the outer two small floor panels: fastener sticks to plastic/foam base.

- **SIDES**
Use self-adhesive pads to attach to plastic panels
- **FRONT**

The six hook & loop fastener straps pass around each of the corresponding head rest posts.

REAR PLUS/SPLIT : The headrest straps **MUST** be unfastened before the rears seats are folded.

TAILGATE COVER – Optional Extra

Use self-adhesive pads to attach to plastic panels