

FITTING INSTRUCTIONS

hatchbag.co.uk

Vauxhall Meriva 2003 - 2010 Our Reference H0321

PACKING REQUIREMENTS

BOOTLINER

10 x self-adhesive loop fastener tabs 800mm 20mm wide self-adhesive loop fastener



Please note this photo shows a Rear Plus with split seat version liner

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any hook & loop fasteners pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.**



NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.

PREPERATION

- Remove the load space cover cassette.
- Ensure the four "D" rings are flush with the floor.
- Slide the seat belts out of their "tidy" loops

BASE PANEL

• Position the base snugly into place. The hook fasteners will attach directly to the carpet.

FRONT PANEL

- Pass the hook & loop fasteners straps around the headrest posts and fasten close to the liner.
- Should you have a Seat Split version: The hook fastener welds attach directly to the carpet on the back of the seats.
- Pass the elastic loops over and behind the seat belt "tidy" loops. Replace the seat belts into the plastic "tidy" loops.

Rear Plus version liners – you will need to unfasten the headrest hook & loop fastener straps and elastic loops before you attempt to fold your 2nd row seats flat!

SIDE PANELS

- Position the side panels snugly into place.
- Some vehicles have two hooks to the tailgate end of the sides: the liner has slots which you can pass over the top.
- Use the self-adhesive loop fastener tabs to attach the panels to the plastic.
- Photo A + B ; Should you wish to relocate the load cover cassette: Carefully introduce the load cover into the car from above the liner and at a 45' angle. Once locked into place it can be straighten up taking care not to dislodge the fasteners on the leading edge of the sides.





OPTIONAL EXTRAS

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower Headrests.
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.

LOWER HEADRESTS





BUMPER FLAP

Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.

The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.

Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.

FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The **Floor extension** is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.

The max width is 148cm (see photo on left). It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION AS YOU PLACE YOUR ORDER

Please note the Bumper Flap, Seat Flap and Floor extension cannot be added at a late date



