

## Porsche Cayenne 2003-2010 – our ref: H0359

### NET + COVER?

#### NET

Load Safety Net / Partition Net



*The panel against the back of the seats finishes just under the fixed load safety net*

*Refer to the fitting instructions for further information*



*If you purchase a "NET" version Bootliner you cannot remove the Net cassette.*

#### COVER

Load cover



*Holes are cut in the Bootliner to accommodate the relocation of the load cover*



*Refer to the fitting instructions for further information*