

## TOYOTA LANDCRUISER AMAZON

2003 - 2007

### 3RD ROW SEATS REMOVED

REF: H0363

#### PACKING REQUIREMENTS

- BOOTLINER  
17 self-adhesive loop fastener tabs
- TAILGATE COVER  
6 self-adhesive loop fastener tabs

#### BEFORE ATTEMPTING TO FIT LINER:

If you have a 3rd row of seats + seat belts: Pull on seat belt to give some slack. Make a small fold in webbing close to the floor and push this folded edge into the void between the carpet and the plastic side panel. Carefully remove the slack. Place seat belt catch above the seat belt tidy. The seat belt webbing now sits flush along the contours of the side panels.

#### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not disturb during.



Place liner into car and unfold. The panel with the Hatchbag label sits against the back of the rear seats.

#### FITTING

##### BASE

- Tailgate end of floor: Slip the pocket (on the rear side of liner) over the tailgate hinge cover.
- Position the base snugly into place.
- Attach all four ties to the luggage hooks in floor panel

##### FRONT PANEL

- Pass hook & loop fastener straps around the head rest posts and fasten close back onto liner

##### SIDE PANELS

- Position side panels snugly into place and fix to plastic with self-adhesive loop fastener pads (supplied separately).
- Ties attach up and over the roller blind.
- Offside side panel: The hook fastener tab attaches to the plastic trim with self-adhesive loop fastener pads: holding the front of the side panel taught.

#### OPTIONAL EXTRA - TAILGATE COVER

The fastener extension tabs attach to the vehicle using self-adhesive loop fastener pads (supplied separately). **NOTE:** the top tabs fold over the edge of the tailgate. Pass the elastic loops over the corners of the carpeted panel