

BMW 3 Series Touring – 2005 to 2012

Our ref: H0395

Year Identification

1999 – 2005

This boot liner is not available



Plastic panel

H0395

2005 – 2012

This boot liner suits your vehicle. Please carry on with your purchase.



Offside net flush to side wall

H0545

2012 – 2019

This boot liner **does not** suit your vehicle.

Please re-select the appropriate model from our list.



Offside net flush to side wall