

FORD GALAXY 2006 on

Our ref: H0413

Packing requirements

BOOTLINER



Min of 16 self-adhesive loop fastener pads

1200mm cut length of 20mm wide self-adhesive loop fastener.

2 x Ref 119 – Hook/loop straps



REF:119



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fasteners pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion do not disturb during.



PREPARATION

- Remove the load cover. *It may be replaced later if you have requested "Load cover in" version.*
- Remove the "Load protection NET"
- Slide the rear seat as far back to the tailgate. Fold the 3rd row seats flat into the floor.
- Unfold the Hatchbag and place in the vehicle. The panel with the Hatchbag label will sit against the back of the rear seat.

ROW 3 SEAT BELT PREPARATIONS

- Using the REF: 119 straps fix the row 3 seats belts as illustrated in the photo. *(Some Galaxy models have 3rd row seat belts that can be unclipped from the car floor. They will not require this fastener here)*

1. Push seat belt right into corner before attaching the fastener



2. Remove the paper backing and fix to the plastic trim

BASE

- Position the base snugly into place. Start behind the back of the rear seats
- The hook fasteners welded to the reverse face of the liner will attach directly to the floor carpet.



FITTING FRONT

- Hook & loop fasteners straps align to headrests.
- Pass around each post and fasten back onto themselves.



REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS / THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo)**

SIDES

- Carefully position the side panels snugly into place.
- Use both the long length + pre-cut tabs of self-adhesive loop fasteners to fix the sides to the plastic trim

AIR VENTS / INTERIOR LIGHTS

We try to keep the openings in our liners to a "minimum". If you wish to access an Air Vent, "D" Ring, Interior Light, or fit the Load Cover back into the vehicle where we have NOT made the openings then you can "carefully" cut the liner yourself.

NEVER cut the bindings or ANY sewn seam. The PVC fabric does not fray.



Optional extras

Please note these photos are non-specific to your car.

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- Lower the headrest before fitting the flap, so as not to impair the driver's rear view.
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts
- The Seat Flap can also be used in conjunction with the Rear Plus Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests

BUMPER FLAP

- Fit Boot Liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.

