

HYUNDAI SANTA FE 7 SEATER

2006 -2012

3rd Row seats folded down

Our ref: H0424

Packing requirements

- BOOTLINER
Minimum of 22 self-adhesive loop fastener tabs
- REAR DOOR COVER
Minimum of 19 self-adhesive loop fastener tabs



Photo shows a Rear Plus version

PREPARATION

- Remove the load cover cassette; it may be replaced later.
- Clips the 3rd row seat belts into their appropriate “tidy clips”
- Unfold the Bootliner and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.



FITTING

BASE

- Position the base of the liner snugly into place. Start at the tailgate end. **PLEASE NOTE:** It is the same size as the boot base and does not cover the small void at the front.
- Hook fastener welds attach directly to the carpet.



FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten close back onto themselves.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS + THE HEADREST STRAPS BEFORE YOU FOLD THE REAR SEAT UPPERS** Please refer to **REAR PLUS** options on website to see detailed photo's



SIDES

- Carefully position the side panels snugly into place.
- Use both the small tabs and long length of the self-adhesive loop fasteners to attach the side to the plastic trim.



OPTIONAL EXTRAS

TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



Please note: Photos are non specific to your vehicle

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



BUMPER FLAP

- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



BOOT LINER EXTENSION

The “Boot Liner Extension” offers additional protection when the rear seats are folded by extending coverage to the Driver & Front passenger seats.

- The Boot Liner Extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat. The max width is 148cm (see photo on left). It will offer no protection to the rear doors



(This item cannot be added at a later date)