

## NISSAN X-TRAIL 2007-2014

Pat ref H0434



Please note: Photo shows a Rear Plus boot liner, prepared for a bumper flap, with additional split front.

### Our Packing instructions

- BOOTLINER**  
Minimum 34 x self-adhesive fasteners  
2 x 350mm cut lengths of self-adhesive fasteners
- TAILGATE COVER**  
Minimum 20 x self-adhesive fasteners



### IMPORTANT PREPARATION

To ensure a good bond; when using the self-adhesive hook & loop fastener to attach the Bootliner to the plastic / metal

trim (Not the carpet), it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords.

Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

### PREPARATION

Remove the load cover before fitting the liner. It can be replaced once you have completed.

### FITTING

- Place the boot liner into the car and unfold. The panel with the Hatchbag label goes towards the front of the car
- Position the base of the liner snugly into place. Attach to the floor using the self-adhesive loop fastener pads, ensuring you follow the preparation advice above
- Place the front panel of the liner up against the back of the rear seat. Fasten the 6 hook & loop fastener straps around the corresponding headrest posts and fasten close back onto themselves. The two elastic loops fit over the corresponding seat locking buttons.
- Position the side panels snugly into place. Attach using the self-adhesive loop fastener pads and the two cut lengths.

### OPTIONAL EXTRA: REAR DOOR COVER

- Use the self-adhesive loop fastener pads to attach the cover to the plastic trim.