

CITROEN C5 Estate (Mk III) 2008on

OUR REF: H0444



Please note; this liner is a rear plus liner, with additional seat flap, bumper flap, and window sills.

Packing instructions

BOOT LINER

- SPLIT ONLY - 1x self-adhesive fastener tab

SILL FLAPS - 4 x 280mm long cut lengths of self-adhesive loop fastener

- Minimum of 13 x self-adhesive loop fastener pads

TAILGATE COVER

- Minimum of 20 x self-adhesive loop fastener pads

VERY IMPORTANT PREPARATION

To ensure a good bond; when using the self-adhesive fastener to attach the Bootliner to the plastic / metal

trim (**Not** the carpet), it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover " made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

PREPARATION

Remove the load cover before fitting the liner. It can be replaced once you have completed.

FITTING

- Place the Bootliner into the car and unfold. The panel with the Hatchbag label goes towards the front of the car
- Position the base of the liner snugly into place. The hook fastener strips will attach directly to the hook fastener friendly carpet. (Ensure the carpet is clean and free of Dog hair)
- Place the front panel of the liner up against the back of the rear seat. Fasten the 6 hook & loop fastener straps around the corresponding headrest posts and fasten close back onto themselves.
- Position the side panels snugly into place. The hook fastener strips will attach directly to the hook fastener friendly carpet.



SPLIT SEAT LINER ONLY

- **Photo A** 60% seat kept upright: attach the fastener tab with the self-adhesive loop fastener to the plastic plate.

ADDITIONAL WINDOW SILL FLAPS

- Attach the flaps to the bootliner sides.
- Use the long lengths of self-adhesive loop fastener to attach the flaps to the plastic window sills.