

BMW X5 - 2007 - 2018 (inc. 2014 facelift)

5 seater

Our ref: H0447

PACKAGING REQUIREMENTS.



BOOTLINER

- **2 x 430mm - 20mm wide** self-adhesive loop fastener
- **10 x tabs** self-adhesive loop fastener



TAILGATE COVER

- **20 x tabs** self-adhesive loop fastener



DROP DOWN TAILGATE COVER

- **19 x tabs** self-adhesive loop fastener



STEP I. PREPERATIONS

- Remove the load space cover cassette. This can be replaced carefully once the Boot liner has been fitted.
- Unlock the 2nd row seats and fold down flat.



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.



STEP 2. FITTING BASE

- **Photo A.** Starting at the tailgate end fit the pocket over the drop down rear tailgate.
- Position the base of the liner snugly into place.
- **Photo B.** Push the foam filled tabs into the void between the floor and the rear seat uppers. It is a bit of a squeeze! (This photo is non-specific to your car)
- Carefully re-lock the 2nd row seats.



STEP 3. FITTING THE FRONT

- **Photo C.** Pass the fastener straps around the headrest posts and fasten close to the liner.
- **Photo D.** Pass the elastic strap around the middle headrest and fasten close to the liner.

REAR PLUS

Please note on REAR PLUS version liners – you will need to unfasten the headrest straps before you attempt to fold your 2nd row seats flat!



STEP 4. FITTING THE SIDES

- Position the side panels snugly into place.
- Use the self-adhesive loop fastener to attach the sides to the plastic panels.
- **Image E.** Attach the two hook fastener tabs to the plastic moldings that take the load cover cassette, using the self-adhesive loop fastener pads – trim excess.



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive fastener tabs will be stuck. (image 4)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5C. BUMPER FLAP

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. Ensure you do not cut through the stitching
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound

