

NISSAN Pathfinder 2005on
(3rd row seats folded into floor)

OUR PATT REF: H0449-R3FLD

Our packing requirements

- Bootliner
- Min 32 self-adhesive loop fastener pads
- 2 of self-adhesive loop fastener + webbing straps (our ref: 119)
- Rear Door Cover
- Min 21 self-adhesive loop fastener pads



REF:119



PHOTO A



PHOTO B

IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone.

Before applying any self-adhesive fasteners pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone) We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: The adhesive takes 24hrs to reach full adhesion – do not disturb during this time. In cold weather we advise you to fit the liner in a warm environment (i.e. run the car till the interior is warm)

- Remove the load space cover cassette and nearside storage net: **PHOTO A**
- Using the 2 of self-adhesive loop fastener + webbing straps (our ref: 119) to fix the 3rd row seat belts as indicated in **PHOTO B**, so that they lie flush to the car side panel. (Remove paper backing and fix over seat belt.)

FITTING

- **BASE:** Starting at the tailgate end, position base of the liner snugly into place. Attach the two ties to the corresponding luggage hooks. Use the self-adhesive loop fasteners to attach the liner to the metal tailgate plate. To the front, the hook fasteners welded to the reverse face of the liner will attach directly to the carpet. (Note: the base does not span the void behind the rear seats)
- **FRONT PANEL:** Pass the hook & loop fastener straps around the headrest posts and fasten close to the liner. The hook fasteners welded to the reverse face of the liner will attach directly to the carpet.
- **SIDE PANELS:** Position the side panels snugly into place. Use the self-adhesive loop fasteners to attach the sides to the plastic panels.
- *Please note on REAR PLUS version liners – you will need to unfasten the headrest straps before you attempt to fold your 2nd row seats flat!*



Optional extra – Rear Door Cover

Use the self-adhesive loop fasteners to attach the cover to the plastic panel.