

NISSAN Pathfinder 2005-2014

3rd ROW SEATS IN (upright and usable)

OUR PATT REF: Ho449-R3USE



- Our packing requirements
- Boot liner
 - Min 24 self-adhesive loop fastener pads
- Rear Door Cover
 - Min 21 self-adhesive loop fastener pads

IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim.

Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone.

Before applying any self-adhesive fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone) We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: The adhesive takes 24hrs to reach full adhesion – do not disturb during this time. In cold weather we advise you to fit the liner in a warm environment (i.e. run the car till the interior is warm)



Photo A

Optional extra: Rear Door cover

PREPARATION

- Remove the nearside storage net: PHOTO A

FITTING

- **BASE:** Starting at the tailgate end, position base of the liner snugly into place. Use the self-adhesive loop fastener to attach the liner to the metal tailgate plate. To the front, the hook fasteners welded to the reverse face of the liner will attach directly to the carpet.
 - **FRONT PANEL:** The hook fasteners welded to the reverse face of the liner will attach directly to the carpet.
- Please note on REAR PLUS version liners – you will need to carefully unfasten the hook & loop fasteners on the seat backs before you attempt to fold your 3rd row seats flat!*
- **SIDE PANELS:** Position the side panels snugly into place. Use the self-adhesive loop fasteners to attach the sides to the plastic panels.

Optional extra – Rear Door Cover

Use the self-adhesive loop fasteners to attach the cover to the plastic panel.