

## AUDI A4 Avant 2008-2015

Our ref: H0458  
(Incl. Allroad / Quattro / S4)

Packing requirements:

- BOOTLINER – Requires no additional fixings.
- REAR DOOR COVER - Minimum of 17 self-adhesive fastener tabs

### PREPARATION

- Remove the load space cover cassette
- Vehicles with Safety net cassette: Unlock rear seat uppers and fold flat.



*Photo shows: Rear Plus with Seat Split version*

### FITTING

#### BASE PANEL

- Position the base of the liner snugly into place.
- The hook fasteners welded to the reverse face will attach directly to the carpet.

#### SIDE PANELS

- Position the side panels snugly into place. The hook fasteners attaches directly to the carpet.

#### FRONT PANEL

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.

If the Safety net cassette is to remain in place:

- **Photo A:** With the rear seat uppers folded flat. Temporarily lay the headrest straps over the top of the cassette to keep them free and at hand whilst you relock the seat uppers
- **Photo B:** Lift the straps off the cassette and pass them around the headrest posts and fasten close.

*Rear Plus version liners – you will need to unfasten the headrest hook & loop fastener straps before you attempt to fold your 2<sup>nd</sup> row seats flat!*



#### OPTIONAL EXTRAS

Rear Door Cover - Use the self-adhesive loop fastener supplied to attach the sides to the plastic panels.

#### REAR DOOR COVER IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fastener pads cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not touch during.