



Mini Hatchback 3 door - 2007 to 2014

our ref: H0459

PACKAGING REQUIREMENTS:

☐ BOOT LINER

8 x tabs self-adhesive loop fastener

TAILGATE COVER NOT AVAILABLE



Rear Plus boot liner



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you MUST CLEAN all grime from the plastic and REMOVE all SILICONE applied during manufacture and valeting.

To do this please:

- 1. Use a silicone remover, such as AutoGlym Intensive Tar Remover, and apply generously to the surface you want to adhere to.
- 2. Using a separate clean, dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 and 2 if necessary.) Extra tabs have been provided.
- 3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

*The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.





Please note: not all of the photographs are specific to your vehicle

STEP 1. PREPARATIONS

Remove the load cover. It may be replaced later.

06/01/2021 | v. 0 page. 1

STEP 2. FITTING THE BASE

 Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners on the back side attach directly to the carpet. (Image A)



STEP 3. FITTING THE FRONT

- PLUS / SPLIT VERSION ONLY Fasten the hook & loop fasteners between the side panels and the seat panel. (Image B)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts.
 (Image C). Make sure to hold the front part of the base in position to avoid pulling the boot liner too far up. Repeat the procedure with the left and right headrests.




Image B

REAR PLUS VERSIONS

You MUST unfasten the hook & loop fasteners and the headrest straps before you recline the upper part of the rear seats. (Please refer to REAR PLUS / SPLIT options on website to see detailed photo.)



STEP 4. FITTING THE SIDES

 Attach the hook fastener on the top edge and tailgate end of the boot liner sides directly onto the carpeted sides of the boot area. (Image D)



STEP 5. FITTING THE BACK

• Stick the 8 x self-adhesive loop fastener tabs to the plastic panel located at the tailgate end of the side of the boot area, aligned with the hook fastener on the back of the boot liner. (Image E)



06/01/2021 v. 0 page. 2

OPTIONAL EXTRAS

STEP 5A. SEAT FLAP (SEMI-TAILORED)

- The semi-tailored seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- Raise the headrests.
- Sitting in the passenger seat area with the largest section of the semi-tailored seat flap facing you and the smaller sections facing the boot. Place the middle section over the top of the rear seats and feed the smaller shaped sections with hook and loop fastener under and around the headrest posts. (Image 1)
- Attach the smaller shaped sections to the loop fastener on the Boot liner just below the top of the rear seats. (white arrow - Image 2 & 3)

Rear Plus or Split Option(s) ONLY

The additional rectangle seat flap is to be used when the rear seats are in the folded position to extend the coverage forward. (Image 4 - Please note: the photo is not specific to your vehicle.)

STEP 5B. BUMPER FLAP

- Fit the boot liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the boot liner. (Image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.











06/01/2021 v. 0 page. 3

OPTIONAL EXTRAS PAGE 2

Please note: the following photos are not specific to your vehicle.

STEP 5D. BOOTLINER EXTENSION

The Bootliner extension provides superior protection for the rear seats when purchased with a REAR PLUS option. (Image 6)

- The Bootliner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection for the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max. width is 148cm (Image 6)
- It offers no protection to the rear doors





STEP 5E. FREQUENT USE KIT

 If you frequently remove/install your boot liner from/ to your vehicle, please note that the carpet will "fluff" up – we offer an alternative Frequent Use Fitting Kit (Image 7+8)

The Frequent Use Kit is available to from our on-line Store – simply add it to your order from the Store. The kit can also be ordered at a later date.





06/01/2021 v. 0 page. 4