

## Jaguar X Type Saloon 2001-2010

Our ref: H0468

### Our Packing requirements

- Minimum of 1 self-adhesive loop fastener tabs
- 4 x black plastic and loop fastener straps our ref: 120



### IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive hook & loop fastener to attach the boot liner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone.

Before applying any hook & loop fastener pads, the surface MUST be thoroughly cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone) We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: The adhesive takes 24hrs to reach full adhesion – do not disturb during this time. In cold weather, we advise you to fit the liner in a warm environment (i.e. run the car till the interior is warm)



### FITTING

#### BASE PANEL

- Position the base of the liner snugly into place. The hook fastener will attach directly to the carpet.

#### SIDE PANELS

- Position the side panels snugly into place. The hook fastener will attach directly to the carpet.

#### FRONT PANEL

- Position the front of the liner snugly into place. The hook fastener will attach directly to the carpet.

#### BACK PANEL

*Please note photos A – C are non-specific to your car*

- Locate the 4 slots and hook fastener welds in the back panel: you now need to fit the following plastic/ loop fastener straps (our ref: 120)
- In line with each slot, insert the plastic section of one of the straps under the rubber seal and behind the plastic panel (See photo A). ENSURE THE WRONG SIDE OF THE LOOP FASTENER FACES UPWARDS.
- Pass the loop fastener through the slot in the flap (See photo B) and fasten-close (See photo C)
- Use the self-adhesive loop fastener to attach the center of the back panel snugly into place