

PEUGEOT 308 HATCH 2007on

OUR PATT REFH0474



- Packing requirements
- BOOT LINER**
Min x 4 self-adhesive loop fastener pads
3 cut lengths of self-adhesive loop fastener:
2 @ 270mm long
1 @ 175mm long
- REAR DOOR COVER**
Min x 20 self-adhesive loop fastener pads



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (Not the carpet), it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any loop fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

Remove the load cover before fitting the liner. It can be replaced once you have completed.

FITTING

BASE PANEL

Place the boot liner into the car and unfold. The panel with the Hatchbag label goes towards the front of the car. Position the base of the liner snugly into place. The hook fastener strips will attach directly to the hook fastener friendly carpet. (Ensure the carpet is clean and free of Dog hair)

FRONT PANEL (back of seats!)

Fasten the 6 hook & loop fastener straps around the corresponding headrest posts and fasten close back onto themselves. The hook fastener welds on the reverse side of the liner attach directly to the carpet on the back of the seats.

BACK PANEL + SIDES

Position the side panels snugly into place Use the self-adhesive loop fastener pads to attach the liner to the plastic. See Photo A: Use the longer lengths of self-adhesive loop fastener to attach the back panel of the liner.

See Photo B: Attach the shorter length of self-adhesive loop fastener along the inside face of the plastic pocket panel. The two ties attach to the rear seat catches.

Removing the Hatchbag: Take time to carefully peel off the hook fastener from the carpet.