

HONDA JAZZ 2008 to 2014

Our ref: Ho484



Packing requirements

- ☐ Boot Liner - Minimum of 33 self-adhesive loop fastener tabs

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**. **NOTE:** the adhesive takes 24hrs to reach full adhesion – do not disturb during.



PREPARATION

Remove the load cover cassette. It can be replaced later.

FITTING

BASE

- Place the liner into the car and fit the base snugly into place. The hook fastener welds on the reverse face of the base panel will attach directly to the carpet.

FRONT *(Has the Hatchbag label)*

- Pass the hook & loop fastener straps around each corresponding headrest posts, and fasten close upon themselves

SIDES

- Position the side panels snugly into place.
- Unlock the rear seat uppers and recline a little. Attach the two ties to the corresponding metal seat locking bars. The top front corners will sit behind the seats a little.
- Use the self-adhesive loop fastener tabs to attach the sides to the plastic trim.
- Re-lock the rears seat uppers.

BACK

- Position snugly into place and use the self-adhesive loop fastener tabs to attach to the plastic trim.