

Peugeot 308SW (S + SR) – 2008 – 2014 - our ref H0485

We have two versions available for your vehicle; please consider the following points carefully

## HIGH Sides



## HIGH SIDES

- Offers maximum coverage to the sides of the boot.
- Sides attach to the carpet and the plastic, see fitting instructions below.
- You can NOT replace the load cover cassette once the Bootliner is fitted.

## STANDARD Sides



## STANDARD SIDES

- Covers the carpeted area of the boot.
- You CAN replace the load cover cassette once the Bootliner is fitted.