

## TOYOTA COROLLA 5dr Hatch 2002 -2007

(Designed to fit a boot with a FULL size spare wheel)

Our ref: Ho486



### PACKING REQUIREMENTS

- ☐ BOOTLINER  
2 x 350mm cut lengths of self adhesive loop fastener.
- ☐ REAR DOOR COVER  
Minimum of 16 self-adhesive loop fastener tabs

### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive Velcro to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any Velcro pads, the surface **MUST be thoroughly cleaned** using a silicone remover. (The Velcro cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

**NOTE:** the adhesive takes 24hrs to reach full adhesion, do not disturb during.



### PREPARATION

Remove the load cover cassette. It can be replaced later.  
Ensure all tie down rings are lying flat.

## FITTING

### BASE

- Place the liner into the car and fit the base snugly into place. The hook fastener welds on the reverse face of the base panel will attach directly to the carpet.

### FRONT *(Has the Hatchbag label)*

- Pass the hook & loop fastener straps around each corresponding headrest posts, and fasten close to the corresponding hook fastener welds.

### SIDES

- Position the side panels snugly into place. The hook fastener welds on the reverse face will attach directly to the carpet.
- The ties attach to the rear seat's chrome locking bars.

### BACK

- Use the long strips of self adhesive loop fasteners to attach the back panel to the plastic trim.

**DO NOT** constantly take the liner in and out. The hook fasteners will cause the fibers' of the carpet to fluff up: This will impair the liners function.

Should you wish to use the load tie down hooks or webbing straps: You can carefully cut slots into the PVC fabric. Ensure you **DO NOT CUT** through the stitching / black tape.

### REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS**

### REAR DOOR COVER

- The hook fastener welds on the reverse face of the door cover will attach directly to the carpet.