

STANDARD SIDES

PEUGEOT 308SW 2008-2014

SPORT + SE Models (7 Seater - 3rd row seats out)

Our ref: Ho487STND

Packing requirements

BOOT LINER

Does not require any additional fixings

REAR DOOR COVER

Minimum of 23 self-adhesive loop fastener tabs

PREPARATION

Remove the load cover cassette.
It can be replaced later.

FITTING

BASE

- Place the liner into the car and fit the base snugly into place. The hook fastener welds on the reverse face of the base panel will attach directly to the carpet.
- Attach the two ties to the corresponding seat lock bars, and the luggage tie down loops.

FRONT (Has the Hatchbag label)

- Pass the hook & loop fastener straps around each corresponding headrest posts, and fasten close back upon themselves.
- The hook fastener welds on the reverse face of the front panel will attach directly to the carpet.

SIDES

- Carefully position the side panels snugly into place. The hook fastener welds on the reverse face of the panel will attach directly to the carpet.

If you intend to frequently remove/fit the boot liner from/to your vehicle please note that carpet will "fluff" up – we can provide an alternative frequent use fitting kit at an additional cost of £5.00.

REAR PLUS VERSIONS

YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS

Optional Extras

Please note the following photos are non-specific to your vehicle

BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



NOTE: Photo is not the actual model



TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



VERY IMPORTANT TAILGATE PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any loop fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

