

Volvo XC60 2008-2010

Our Ref: Ho490

WITH Safety net removed from the back of the rear seat

Boot Liner Packing requirements

Minimum of 6 self-adhesive loop fastener tabs
30mm wide self-adhesive loop fastener strips
cut:

2 x 300mm + 2 x 170mm

6 x ref: 121 (plastic + loop fastener)

4 x ref: 099 (plastic with hook & loop fastener)

2 x own base tabs



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.

PREPERATION

Remove the load cover cassette. (*It may be replaced later, assuming you have ordered the "Cargo cover (load cover) to be left in" version.*)

- Unlock the rear seats and fold flat.



Photo A



Photo B



Photo C

FITTING

BASE

- Place the liner into the car and fit the base snugly into place.
- Locate the position of the 6 hook fastener welds on the reverse side of the liner, at the tailgate end.

Photo A + B

Lift up the false floor. Attach the two Long Base Tabs to the floor's carpet. The hook fastener section will attach directly to the carpet.

Photo C

The tabs will protrude out of the floor panel when its replaced allowing the liner to be fasten closed to them.

Photo D

- Ensure the base is sitting straight and not skewed before you.....
- Push the two foam tabs down into the void between the rear seat and the boot floor.
- Re-lock the rear seat uppers.



FRONT

Photo E+F

- Lift the central headrest, and wrap the large elastic strap around both posts. Fasten, then re-position the headrest.

Photo G

- Pass the corresponding elastic straps around each of the outer headrest posts, and fasten onto the hook fastener welds below.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS OR HEADRESTS (Please refer to REAR PLUS options on website to see detailed photo')**
- Use the self-adhesive loop fastener pads to attach the upper corners to the plastic.



SIDES

- Place the side panels' snugly into place.

Photo H

- Locate the 2 x2 slots along the top edge of the liner.
- In line with these insert the loop fastener / plastic tabs ref: 099 into the air vent on the side of the car. Take care not to drop them down into the vents
- Ensure the right side of the loop fastener faces upwards when it is hanging down

Photo I+J

- Pass the loop fastener through the slots in the liner and fasten back on themselves.



Photo K



Photo L

Photo K+L (6 x ref: 121)

- At the tailgates end: Pull back the rubber seal and slide the plastic part of the clip (ref. 121) behind the carpeted panel. The loop fastener section will remain exposed. See Photo L
- Re-align with the hook fastener welds on the liner and fasten.

Photo M

- Use the various lengths of self-adhesive loop fastener to attach the remaining hook fastener to the plastic trim.

The 2 additional ties can be fastened around the rear seat locking bars. DO NOT tie tight as it will lift the floor of the liner. They are designed just to reduce shift on the sides when the Rear Plus liner is folded flat with the rear seats.



Photo M

Photo N+O

Photos show the "Cargo cover (Load cover) to be left in" version Boot Liner.



Photo N



Photo O

Nearside + Offside views of a “Rear Plus -Cargo cover (Load cover) to be left in” version Bootliner



OPTIONAL EXTRAS

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.

