

## VAUXHALL INSIGNIA TOURER

2009 - 2017

Our ref: HO495 \_STAND & HIGH

### PACKING REQUIREMENTS

- HIGH SIDES BOOT LINER**  
4 x self-adhesive loop fastener tabs  
100mm 20mm length of self-adhesive loop fastener
- STANDARD SIDES BOOT LINER**  
Requires no additional fixings
- TAILGATE COVER**  
23 x self-adhesive loop fastener tabs



*image shows high sided version*

### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the Boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately, we are unable to supply this product, as it cannot be transported via our postal carrier.

**NOTE:** the adhesive takes 24hrs to reach full adhesion, do not disturb during.



### PREPARATION

Remove the load cover cassette. It can be replaced later, if you do not have a High sided Boot liner or a rear door cover!

### FITTING

#### BASE

- Place the liner into the car and fit the small section of base snugly into place. The hook fastener welds on the reverse face of the base panel will attach directly to the carpet.

#### FRONT (Has the Hatchbag label)

- Pass the hook & loop fastener straps around each corresponding headrest posts, and fasten close back upon themselves.
- The hook fastener welds on the reverse face of the front panel will attach directly to the carpet.

**REAR PLUS VERSIONS - YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS**

## SIDES

- Carefully position the side panels snugly into place.
- STANDARD SIDES – The hook fastener welds on the reverse face of the panel will attach directly to the carpet.
- HIGH SIDES - Use the self-adhesive loop fasteners to attach the upper section of the side panels to the plastic trim.

If you intend to frequently remove/fit the Boot liner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent use fitting kit” – ask our sales team or see our on-line “factory shop”.

## OPTIONAL EXTRAS

### TAILGATE COVER

Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



PLEASE NOTE: There is a small separate section of load cover which fixes to the rear door. Whilst the Hatchbag Tailgate cover is in situ you will not be able to refit this.

### BUMPER FLAP

1. Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
2. The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



## SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower Headrests.
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.



## FLOOR EXTENSION

The “Floor extension” offers superior protection to the rear seats when purchased in conjunction with a **REAR PLUS** option.

- The **Floor extension** is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat. The max width is 148cm (see photo on left).

It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION

AS YOU PLACE YOUR ORDER



Please note the Bumper Flap, Seat Flap and Floor extension cannot be added at a late date