

FITTING INSTRUCTIONS hatchbag.co.uk

CITROEN C4 HATCH 2004 to 2011

Our ref: H0496

Packing requirements	
	BOOTLINER Minimum of 9 self-adhesive loop fastener tabs
	TAILGATE COVER Minimum of 20 self-adhesive loop fastener tabs



Photo shows a Rear Plus with Seat Split version

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fastener pads, the surface MUST be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.



PREPARATION

• Remove the load cover cassette. It can be replaced later, if you do not have a rear door cover!

FITTING

BASE

• Place the liner into the car and fit the base snuggly into place. The hook fastener welds on the reverse face of the panel will attach directly to the carpet.

FRONT (Has the Hatchbag label)

- Unlock the rear seat back rest and recline just enough to fit the two upper corners. Align the top edge of the liner with the top of the seats. Ensure you align the cutouts with the seat locking recesses. The hook fastener welds on the reverse face of the front panel will attach directly to the carpet. Relock seat.
- Pass the hook & loop fastener straps around each corresponding headrest posts, and fasten close back upon themselves.

SIDES

PLEASE NOTE: the Bootliner accommodates the offside recess, providing access to the storage facility. However it was not possible to offer the same access to the nearside recess.

- Carefully position the side panels snugly into place.
- The hook fastener welds on the reverse face of the panel will attach directly to the carpet.
- Use self adhesive loop fastener pads to fix the flap to the inner face of the offside pocket.

BACK

• Carefully position the back panel snugly into place. Use the self adhesive loop fastener pads to attach to the plastic tailgate plate.

FREQUENT USE KIT

If you frequently remove/fit your Boot Liner from/to your vehicle please note that the carpet may "fluff" up – we have an alternative "Frequent Use Fitting Kit"







Optional extras

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the Rear Plus Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the lowered rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

BUMPER FLAP

Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.

REAR DOOR COVER

Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

PLEASE NOTE: You cannot replace the load cover whilst the Rear door cover is fitted.





