

BMW XI 2009 to 2015

Our ref: H0504

Packing requirements

BOOTLINER

- ☐ Minimum of 8 self-adhesive loop fastener tabs

REAR DOOR COVER

- ☐ Minimum of 17 self-adhesive loop fastener tabs



VERY IMPORTANT PREPARATION



To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.

PREPARATION

- Remove the load cover. It may be replaced later
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

BASE

- Position the base snugly into place. Start at the tailgate end. Attach the two ties to the tie down hooks. The hook fastener welds will attach directly to the carpet.
- Use the self-adhesive loop fasteners to attach the back flaps to the tailgate plate.
- Attach the self-adhesive fastener tabs to the hook fasteners on the liner. Peel off protective backing, reposition panel and apply **FIRM** pressure at tab location points to ensure maximum adhesion to structure.



FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fastener welded to the reverse face of the liner will attach directly to the carpet



REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTERS + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS** (*Please refer to REAR PLUS options on website to see detailed photo*)

SIDES

- Carefully position the side panels snugly into place.
- The hook fastener welds on the reverse face of the panel will attach directly to the carpet.



Optional extras

FREQUENT USE KIT

If you frequently remove/fit your Boot Liner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent Use Fitting Kit”

The Frequent Use Kit is available to buy from our “on-line” Factory Shop – simply add it to your order from the Factory Shop.



Please note:

We suggest you cut the tabs in half before use on the area highlight in this photo. (Applies to nearside too)



TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



SEAT FLAP

- The Seat flap is designed to use in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over exposed sections of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.

The Seat Flap may also be used to protect the top of your rear seat giving additional protection from drooling dogs etc.

- Fit liner.
- Remove the two outer headrests.
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. The flap is then placed over the fixed head rest and down the back of the seat back rest



As this obstructs your rear view:

- Mark the width of the central headrest and make two slits in the flap from the plain edge, finishing just before the fastener strip. SEE PHOTO TO LEFT. The outer sections will sit lower: Carefully create openings in the flap to accommodate the outer headrest posts, should you wish to replace them.
- The modified flap is then placed over the fixed head rest and down the back of the seat back rest



BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



(Some photos are non-specific to your vehicle)