

FITTING INSTRUCTIONS hatchbag.co.uk

SEAT IBIZA ST (Estate) 2010 on

Our ref: Ho505

PACKING REQUIREMENTS

BOOTLINER
Minimum of 20 self-adhesive loop fastener tabs
2 lengths 20mm wide self-adhesive loop fastener:
330mm + 180mm

REAR DOOR COVER

Minimum of 21 self-adhesive loop fastener tabs



PREPARATION

- Remove the load cover. It may be replaced later
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fastener pads, the surface MUST be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.





BASE

- Position the base snugly into place. Start at the tailgate end. The hook fastener welds will attach directly to the carpet.
- Use the self-adhesive loop fasteners to attach the back flaps to the tailgate plate.
- Attach the self-adhesive loop fastener tabs to the hook fastener on the liner. Peel off protective backing, reposition panel and apply **FIRM** pressure at tab location points to ensure maximum adhesion to structure.



FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fasteners welded to the reverse face of the liner will attach directly to the carpet on the back of the seats.




REAR PLUS VERSIONS

• YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo')

SIDES

- Carefully position the side panels snugly into place.
- Use the self-adhesive loop fastener to attach
 the side to the plastic trim. Attach the selfadhesive fastener tabs to the hook fasteners on
 the liner. Peel off protective backing, reposition
 panel and apply FIRM pressure at tab location
 points to ensure maximum adhesion to
 structure.
- The two cut lengths of self adhesive fasteners are for the front end of the side panels.
- 4 of the fastener welds at the tailgate end will attach directly to the carpet.







OPTIONAL EXTRAS

FREQUENT USE KIT

If you frequently remove/fit your Boot Liner from/to your vehicle please note that the carpet on the floor and seat back will "fluff" up – we have an alternative "Frequent Use Fitting Kit"

The Frequent Use Kit is available to buy from our "on-line" Factory Shop – simply add it to your order from the Factory Shop.



(These photos are non-specific to your vehicle)

TAILGATE COVER

 Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the Rear Plus Option(s).
 With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.







