

Mercedes E Class 2010 to 2016 - Our Ref: H0508

Please ensure you take time to select the correct boot shape

Boot Shape 1

Has a **recess** on the **nearside**
and
Has a **recess** on the **offside**



Boot Shape 3

Has a **recess** on the **nearside**
and
Has **NO** recess on the **offside** (flush side)



Boot Shape 2

Has **NO** recess on the **nearside** (flush side)
and
Has a **recess** on the **offside**



Boot Shape 4

Has **NO** recess on the **nearside** (flush side)
and
Has **NO** recess on the **offside** (flush side)



Mercedes E Class 2010 to 2016 - Our Ref: H0508

Load Cover Identification

*Is the Load Cover to be left IN or OUT (Removed) from the vehicle when boot liner fitted?
If you select "OUT" the liner is manufactured to cover the locating holes*

