

VAUXHALL ASTRA SPORTS TOURER 2010 to 2015

Our ref: H0511-STANDARD/HIGH

PACKING REQUIREMENTS

- HIGH SIDES BOOT LINER
Minimum of 11 self-adhesive loop fastener tabs
Minimum of 1.5 m cut length of 30mm wide self-adhesive loop fastener
- STANDARD SIDES BOOT LINER
Minimum of 3 self-adhesive loop fastener tabs
Minimum of 1.85 m cut length of 30mm wide self-adhesive loop fastener
- TAILGATE COVER
Minimum of 25 self-adhesive loop fastener tabs



Photo shows HIGH SIDE Version

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



PREPARATION

Remove the load cover cassette. It can be replaced later, if you do not have a High sided boot liner.

Please note some of these photos are non-specific to your vehicle.

BASE

- Position the base snugly into place. Start at the tailgate end.
- The hook fastener welds will attach directly to the carpet.
- Use the self-adhesive loop fastener strip to attach the back to the tailgate plate.



FITTING FRONT

- Fasten straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fasteners will attach directly to the carpet.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS** (Please refer to REAR PLUS options on website to see detailed photo')
- **DO NOT USE THE "QUICKFOLD" RELEASE LEVERS** (Located in the boot /on the rear seat) **BEFORE UNFASTENING THE HEADREST STRAPS** – please note they are covered by the boot liner for this very reason.

SIDES

- Carefully position the side panels snugly into place.
- Use the self-adhesive loop fastener strip and tabs to attach the top of the sides to the plastic.
- The hook fastener welded to the reverse face of the tailgate end of the sides will attach directly to the carpet panels.



OPTIONAL EXTRAS

FREQUENT USE KIT

If you intend to frequently remove/fit the boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent use fitting kit" – ask our sales team or see our on-line "factory shop".



Please note the following photos are non-specific to your vehicle

TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

