

# FITTING INSTRUCTIONS

hatchbag.co.uk

# VW POLO 2009on

Our ref: H0515-LOW / RAISED

## PACKING REQUIREMENTS

#### BOOT LINER

Minimum of 1 self-adhesive loop Fastener tabs Minimum of 600mm cut length of 20mm wide selfadhesive loop Fastener

TAILGATE COVER Minimum of 18 self-adhesive loop fastener tabs



Please note; this shows the RAISED VERSION

# VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.** 

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not disturb during.

# PREPARATION

Remove the load cover. It can be replaced later. Ensure the floor level is appropriate to your model of Boot liner

Please note: some of the photos are non-specific to your vehicle

#### BASE

- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.
- Hook fastener welds attach directly to the carpet.

## BACK

• Use the self-adhesive loop fastener supplied to attach the back panel to the plastic tailgate plate.

#### FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.

## **REAR PLUS VERSIONS**

YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS





#### SIDES

- Carefully position the side panels snugly into place.
- The hook fastener tabs welded on the reverse face of the panel will attach directly to the carpet.

# OPTIONAL EXTRAS

# SEAT FLAP / FLOOR EXTENSION

- The **Seat flap** is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- Attach the Seat Flap to the strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.

PLEASE NOTE The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. The Polo seats are wider than the Boot liner front panel. The seat flap will not offer sufficient coverage when the rear seats are folded.



- The **Floor extension** is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max. width is 148cm (see photo on left). It will offer limited protection to the rear doors.
- PLEASE REQUEST FURTHER INFORMATION AS YOU PLACE YOUR OREDR: (These items cannot be added at a late date)



FLOOR EXTENSION

# TAILGATE COVER

• Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

# **BUMPER FLAP**

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.

# FREQUENT USE KIT

If you frequently remove/fit your Boot Liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent Use Fitting Kit"

The Frequent Use Kit is available to buy from our "online" Factory Shop – simply add it to your order from the Factory Shop.







"LOWERED" VERSION - (Photos show Rear Plus version)



