

VW TOUAREG 2010 - 2018

Our ref H0516

PACKING REQUIREMENTS



BOOTLINER

Minimum of 2 self-adhesive loop fastener tabs



REAR DOOR COVER

Minimum of 19 self-adhesive loop fastener tabs



Photo of REAR PLUS with SPLIT seat version



MOST UPRIGHT

LARGE GAP

Photo A

PREPARATION

- Remove the load cover cassette. It can be replaced later.
- **Photo A.** Ensure the 2nd row seats are positioned most upright and slid as far back to the tailgate.



BASE

FITTING

BASE

- Place the liner into the car and fit the base snugly into place. Position the front of the base to the rear seat end first and work backwards. The hook fasteners welds on the reverse face of the base panel will attach directly to the carpet.

FRONT (Has the Hatchbag label)

- Pass the hook & loop fastener straps around each corresponding headrest posts, and fasten close back upon themselves.
- The hook fasteners welds on the reverse face of the front panel will attach directly to the carpet.

REAR PLUS VERSIONS - YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS





Photo B



Photo C

SIDES

Carefully position the side panels snugly into place.

Photo B:

The hook fasteners welds on the reverse face of the base panel will attach directly to the carpet.

NEARSIDE POCKET / RECESS

Photo C:

Position the top edge of the liner side panel first, then fit the recess section. Fold the pocket flap over and use the self-adhesive tabs to attach it to the inner face of the plastic panel.



Photo D

BOTH SIDES

Photo D:

Place the tailgate edges under the rubber seal.

OPTIONAL EXTRAS

REAR DOOR COVER

Use the self-adhesive loop fastener tabs to attach the cover to only the plastic trim area.



rear door cover (generic photograph)

IMPORTANT PREPARATION for TAILGATE COVER ONLY

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any fasteners pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately, we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

FREQUENT USE KIT

If you frequently remove/fit your Boot Liner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent Use Fitting Kit”
The Frequent Use Kit is available to buy from our “on-line” Factory Shop – simply add it to your order from the Factory Shop.



BUMPER FLAP

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



SEAT FLAP

- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- **REAR SEATS IN UPRIGHT POSITION**
If the Seat Flap is placed over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

