

Boot Liners

BMW X3 2011 on

Our ref: H0518

Packing requirements

BOOTLINER

- Minimum of 16 self-adhesive loop fastener tabs
3 x ref: 124 (hook/loop fastener: @ 140mm long)



REF: 124

REAR DOOR COVER

- Minimum of 19 self-adhesive loop fastener tabs



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately, we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.



PREPARATION

- Remove the load cover/net cassette. They can be replaced later.
- Unlock the rear seat back rests and recline.

(Please note some of the photos are non-specific to your vehicle)

FITTING

BASE

- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

Photos A + B the liner at the tailgate end.

Photo A: Attach the 3 REF 124 Hook / Loop fastener tabs to the floor's inner plastic molding. Use the self-adhesive loop fastener pads (supplied separately)

Photo B: The tabs will protrude out of the floor panel when it is replaced, allowing the liner to be fastened to them.



BASE continued.

Photos C

- Push the two foam tabs down into the void between the rear seat and the boot floor.



FRONT

Photos D

Hook & loop fastener straps align to headrests.

OUTER

- Pass around each post and fasten back onto themselves.

MIDDLE

- Pass around both post and fasten back onto the hook fastener weld.



REAR PLUS VERSIONS

YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS

SIDES

- Carefully position the side panels snugly into place.

TOP EDGE - CARPET

- The hook fastener Welded Tabs on the reverse face of the panel will attach directly to the carpet.

TAILGATE END - PLASTIC

- Use the self-adhesive loop fasteners to attach the side to the plastic trim.



CARPET



PLASTIC TRIM

IMPORTANT NOTICE

1. The right-side storage compartment on the floor of the boot (near the boot door) will be covered by the car boot liner and will not be usable.
2. The left side storage net will be covered up by the car boot liner. *(ONLY APPLICABLE TO BMW X3 MODELS WITH A NET STORAGE)*



(Please note: these photos are non-specific to your vehicle)

Optional Extras

SEAT FLAP

- The Seat Flap can also be used in conjunction with the Rear Plus Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over exposed sections of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.

REAR SEATS IN UPRIGHT POSITION

If the Seat Flap is placed over large headrests, it will obstruct your rear view.

TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.

