

SKODA YETI 2009 on Raised & Lowered Floor Patterns

Our ref: H0518RF & H0519LF

PACKING REQUIREMENTS

- BOOT LINER
Minimum of 30 self-adhesive loop fastener tabs
2.50 m cut length of self-adhesive loop fastener.
- REAR DOOR COVER
Minimum of 16 self-adhesive loop fastener tabs

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



Bar / Storage HOOK system



*Bar / Storage HOOK system
with Window sill flaps
fitted*

BOOT LINER VERSIONS

We have designed 2 different liners for the Yeti to suit models with either the Raised Floor or the Lowered Floor (No spare wheel).

For each version we have designed 3 further options to match the Skoda Yeti Model Variations:-

1. Standard Load Area – Does NOT have Side Bar/ Storage Hook System OR boot mounted CD changer
2. Load Area WITH Storage Hook /Side Bar System AND Boot Mounted CD Changer.
3. Load Area WITH Storage Hook /Side Bar System NO Boot Mounted CD.

PLEASE NOTE: The load cover **MUST** be removed from the vehicle when the sill covers are used.



NO Bar / Storage HOOK system

(Please note: some of the photos are non-specific to your vehicle)

FITTING

Prior to fitting you will need to remove the Load Cover – this can be re-fitted after the boot liner has been fitted UNLESS you decide to use the additional “Sill Covers” (Photo A1)

If your car has a plastic panel on the NS recess, please remove and store it prior to fitting the boot liner. It cannot be reinserted after the boot liner is fitted. (Photo A2)

REAR SEAT POSITIONS

The rear seats are slid as far back to the tailgate cover + the rear seat uppers are upright (This will accommodate a Skoda Dog Guard)



FRONT

- Hook & loop fastener straps align to headrests (Photo B)

OUTER

Pass around each post and fasten back onto themselves.

MIDDLE

Pass around both post and fasten back onto the hook fastener weld

REAR PLUS VERSIONS

YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST



BASE / BACK

- Carefully position the base panel snugly into place.

CARPET

The hook fastener welded tabs on the reverse face of the panel will attach directly to the carpet (Photo C).

PLASTIC TRIM

Cut to length the self-adhesive loop fastener and attach the side to the plastic trim (Photo D). Ensure you push the hook fastener into the grooved surface.



CARPET



THRESHOLD
PLASTIC TRIM

SIDES

HOOK & LOOP FASTENER

We supply a minimum of 2.5 m of “uncut” Loop fastener and pre-cut loop fastener tabs that should be matched with the hook fastener on the liner at the load area sides (Photo E – Bar/ Hook version)



SIDES CONTINUED

Depending upon which model you have the side height will differ, and so will the window sill covers.

Please be guided by the boot liner sides themselves, and attach the appropriate hook & loop fastener in the most suitable position.

Photo F: shows the window sill flaps for the “Bar/hook” versions boot liners.

Photo H: NO Bars/hooks sides  indicates where the loop fastener is positioned for the side panels.

The window sill flaps are fitted after the boot liner.



OPTIONAL EXTRAS

(Please note: these photos are non-specific to your vehicle)

SEAT FLAP

- The Seat Flap can also be used in conjunction with the **Rear Plus /Split options**. With the rear seats in the folded position the Seat Flap extends the coverage over exposed sections of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats.



REAR SEATS IN UPRIGHT POSITION

If the Seat Flap is placed over large headrests it will obstruct your rear view.



YETI REAR SEATS

Rear PLUS / Split Options function with the seats in Part or Full folded positions.



TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

Please note that photo is NOT Yeti Tailgate Cover.



BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



FREQUENT USE KIT

If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent Use Fitting Kit”

The Frequent Use Kit is available to buy from our “on-line” Factory Shop – simply add it to your order from the Factory Shop.

