

PEUGEOT 3008

LOW + LEVEL Floor Patterns

Our ref: H0526LOW & H0526LEVEL

Packing requirements

BOOTLINER

- Minimum of 8 self-adhesive loop fastener tabs
1000 mm of 30 mm wide self-adhesive loop fastener.

REAR DOOR COVER

- UPPER - Minimum of 23 self-adhesive loop fastener tabs
LOWER - Minimum of 7 self-adhesive loop fastener tabs
950mm cut length of 20mm wide self-adhesive loop fastener



NOTE: Photo shows Level version boot liner

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the Bootliner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



PREPARATION

- Remove the load cover. It may be replaced later.
- Ensure the false floor is positioned to suit your order.
- Unfold the Hatchbag and place in the vehicle. The panel with the Hatchbag label sits against the back of the rear seat.

Please note not all of the photographs are specific to your vehicle

BASE

- Pass the pocket over the tailgate hinge flap
- Position the base snugly into place. Start behind the back of the rear seats
- The hook fasteners welded to the reverse face of the liner will attach directly to the carpet panels.



FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- Any hook fasteners welded to the reverse face of the liner will attach directly to the carpet panels.



REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS / use the "Quick-fold Release Levers" (Please refer to REAR PLUS options on website to see detailed photo')**

SIDES

- Carefully position the side panels snugly into place.
- Cut and attach appropriate lengths of the "uncut" loop fastener to the plastic area as illustrated in these two photos to the right.
- Use the pre-cut loop fastener tabs to attach the rest of the side panels to the plastic trim.



Nearside fastener strips positioning



Offside fastener strips positioning

PLEASE NOTE

The boot liner covers both the "Quick-fold Release Levers" and the Torch

However it leaves the offside interior light uncovered



Optional extras

Please note the following photos are non-specific to your vehicle

TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

LOWER TAILGATE SECTION

- Position the uncut length of self-adhesive loop fastener as shown in the photo.



BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. **Ensure you do not cut through the stitching**
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a **REAR PLUS** option.

- The **Floor extension** is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.

The max width is 148cm (see photo on left).

It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION AS YOU PLACE YOUR ORDER (These items cannot be added at a late date)

