

## CITROEN DS3 2010on

Our ref: H0528

### Packing requirements

- BOOTLINER**  
Minimum of 6 self-adhesive loop fastener tabs
- REAR DOOR COVER**  
Minimum of 16 self-adhesive loop fastener tabs



*Please note: Rear Plus version - Custom Colour*

### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fasteners pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.



**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not disturb

### PREPARATION

- Remove the load cover cassette. It can be replaced later.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

### BASE

- Position the base snugly into place. Start at the tailgate end. It has been designed to finish behind the two Tie Down "D" rings and Seat Hinge
- The hook fastener welds will attach directly to the carpet.



*Please note some of these photos are non specific to your vehicle.*

## FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The fasteners will attach directly to the carpet.



## NOTE: REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS** (*Please refer to REAR PLUS options on website to see detailed photo*)

## SIDES

- Carefully position the side panels snugly into place.
- The hook fasteners welded to the reverse face of the sides will attach directly to the carpet panels.



## BACK

- Carefully position the back panel snugly into place.
- The hook fasteners welded to the reverse face of the sides will attach directly to the carpet panels.
- Use the self-adhesive loop fastener tabs to attach the rear end of the sides to the plastic trim.



## Optional extras

### TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



*Please note this photo is non-specific to your vehicle*

## FREQUENT USE KIT

If you intend to frequently remove/fit the Bootliner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent use fitting kit” – ask our sales team or see our on-line “factory shop”.



*Please note the following photos are non-specific to your vehicle*

## BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



## SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

