

## HONDA CIVIC TYPE-R

2015on

Our ref: H0537-R

Packing requirements

- BOOTLINER  
Minimum of 15 self-adhesive loop fastener tabs
- REAR DOOR COVER  
Minimum of 17 self-adhesive loop fastener tabs



Rear Plus with Seat Split Version, prepared for a seat Flap

### PREPARATION

- Remove the load cover cassette. It can be replaced later.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not disturb during.



### BASE

- Position the base snugly into place.
- The hook fastener welds will attach directly to the carpet.



Please note photos are non specific to your vehicle.

## FITTING FRONT

- Hook and loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fasteners will attach directly to the carpet.

### NOTE: REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo' )**



## SIDES

- Carefully position the side panels snugly into place.
- The hook fastener welded to the reverse face of the sides will attach directly to the carpeted section of the panels.
- Use the self adhesive loop fastener tabs to attach the remainder of the sides to the plastic trim.



## BACK

- Carefully position the back panel snugly into place.
- Use the self-adhesive loop fastener tabs to attach the rear end of the liner to the plastic trim.



## Optional extras

### TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

Please note this photo is non-specific to your vehicle



## FREQUENT USE KIT

If you intend to frequently remove/fit the Bootliner from/to your vehicle please note that the carpet may “fluff” up – we have an alternative “Frequent use fitting kit” – ask our sales team or see our on-line “factory shop”.



*Please note the following photos are non-specific to your vehicle*

## BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



## SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

