

Ford C-Max 2010on

Suits NO spare wheel + Small foam compartment ONLY – see below

Our ref: H0541-FLOW

Packing requirements

BOOTLINER

900mm cut length of 20mm wide self-adhesive loop fastener

REAR DOOR COVER

Minimum of 19 Self adhesive loop fastener tabs



3 VERY IMPORTANT POINTS

BOOT FLOOR PREPERATION

The Boot Liner has been designed to suit the following specification.

Under the carpeted floor panel:

1 - There is
NO spare wheel
in the vehicle

+

2 - There is
NO LARGE
Foam Tray

+

3 - There is
ONLY a SMALL
Foam compartment
in the vehicle



SPARE WHEEL + LARGE Foam Tray



NO spare wheel + SMALL Foam compartment

PREPARATION

- Remove the load cover. It may be replaced later.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

Please note not all of the photographs are specific to your vehicle

IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



FITTING

BASE

- Position the base snugly into place. Start from the tailgate end. The base of the liner finishes just behind the rear Seat Sliding mechanism bar handle
- The hook fasteners welded to the reverse face of the liner will attach directly to the carpet panel.

BACK

- Use the self-adhesive loop fastener strip to attach the back panel to the tailgate plate.



FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves. **DO NOT over tighten so as to lift the liner and in turn the carpet floor!**

REAR PLUS VERSIONS – skip to "SIDES" then return here to "FRONT"

- **SPLIT VERSION ONLY:** The hook fasteners welded to the reverse face of the liner will attach directly to the carpet panel.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS** (*Please refer to REAR PLUS options on website to see detailed photo*)



SIDES

- Carefully position the side panels snugly into place.
- The hook fastener welded to the reverse face of the liner will attach directly to the carpet panels.



REAR PLUS VERSIONS

- Before beginning to fit the sides + front panel, fasten close these 2 corner joints together, then fasten front + side panels.

Optional extras

FREQUENT USE KIT

If you frequently remove/fit your Boot Liner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent Use Fitting Kit”

The Frequent Use Kit is available to buy from our “on-line” Factory Shop – simply add it to your order from the Factory Shop.



TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.
- Wrap the loop fasteners over the grab handle and fasten to the hook fastener weld on the cover



Please note photos are non-specific to your vehicle

BUMPER FLAP

- Fit Boot Liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The **Floor extension** is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.

The max width is 148cm (see photo on left).

It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION AS YOU PLACE YOUR ORDER *(These items cannot be added at a late date)*

