

Skoda ROOMSTER

2006on

Our ref: H0559

PACKING REQUIREMENTS

- BOOT LINER**
2mtrs cut length of 30mm wide loop fastener
Minimum of 6 self-adhesive loop fastener tabs
- REAR DOOR COVER**
Minimum of 17 self-adhesive loop fastener tabs



Awaiting boot liner photos

PREPARATION

- Remove the load cover cassette; it may be replaced later.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

REAR SEAT POSITION

Please ensure your rear seats are set at the following configuration to suit the boot liner

Rear Outer seats are **MOST UPRIGHT**

(Middle seat will be most reclined to align with the outer seats)

Rear Seats are slid as far **BACK** to the tailgate



Rear outer seats: Most upright



Rear outer seats: Reclined

VERY VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.



FITTING

BASE

- Hook fastener welds attach directly to the carpet.



FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten close back onto themselves.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU FOLD THE REAR SEAT UPPERS** Please refer to REAR PLUS options on website to see detailed photo's



SIDES

- Carefully position the side panels snugly into place. Use the self-adhesive loop fastener to attach the side to the plastic trim.



Loop fastener



BACK

- Use the self-adhesive loop fastener to attach the back panel into place.



OPTIONAL EXTRAS

BUMPER FLAP

- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



LOWER HEADRESTS

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower Headrests.
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.



TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a **REAR PLUS** option.

- The **Floor extension** is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.

The max width is 148cm (see photo on left).
It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION
AS YOU PLACE YOUR ORDER

(This item cannot be added at a late date)

