

Mini Clubvan 2012on

Our ref: H0562

Packing requirements

- BOOT LINER
Minimum of 5x self-adhesive loop fastener tabs
- REAR DOOR COVER
Minimum of 21x self adhesive loop fastener tabs



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any loop fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 72hrs to reach full adhesion – do not disturb during.



PREPARATION

- Unfold the Hatchbag and place in the vehicle .The panel with the Hatchbag label sits against the back of the mesh grille.

Please note not all of the photographs are specific to your vehicle

FITTING

BASE

- Position the base snugly into place.
- The hook fastener welded to the reverse face of the liner will attach directly to the carpet panels.



SIDES

- Carefully position the side panels snugly into place.
- The hook fastener welded to the reverse face of the liner will attach directly to the carpet panels.



FRONT

- Pass the hook & loop fastener straps around a corresponding mesh bar and then fasten back upon themselves.



BACK

- Use the self-adhesive loop fastener to attach the back panel to the tailgate plate



Optional extras

FREQUENT USE KIT

If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent Use Fitting Kit”

The Frequent Use Kit is available to buy from our “on-line” Factory Shop – simply add it to your order from the Factory Shop.



BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



TAILGATE COVER

- Use the self-adhesive loop fastener to attach the back panel to the tailgate plate.

