

# FITTING INSTRUCTIONS

hatchbag.co.uk

# JEEP Grand Cherokee 2011to 2021

inc 2013 facelift - Our ref: H0566

Packing requirements

**BOOT LINER** 

I x 1650mm cut length of 30mm wide loop fastener Minimum of 6 self-adhesive loop fastener tabs

REAR DOOR COVER (non-facelift version only)

Minimum of 17 self-adhesive loop fastener tabs



# VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.** 





NOTE: the adhesive takes 72hrs to reach full adhesion, do not disturb during.

#### **PREPARATION**

• Remove the load cover cassette; it may be replaced later.

### **FITTING**

#### **BASE**

- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.
- Hook fastener welds attach directly to the carpet.



#### Photos are non-specific to this vehicle

#### **FRONT**

### **OUTER HEADRESTS**

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten close back onto themselves.





# **FOLDING HEADRESTS**

• YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU FOLD THE REAR SEAT UPPERS or DROP THE HEADRESTS.

### FRONT cont.

#### MIDDLE HEADREST

- Lift the central headrest, and loosely wrap the large loop fastener strap behind both posts and fasten to the hook fastener weld. Loosely fasten and then lower the headrest.
- You may need to tighten the hook & loop fastener strap now.





### **REAR PLUS VERSIONS**

• YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU FOLD THE REAR SEAT UPPERS Please refer to REAR PLUS options on





Photos is non-specific to this vehicle

#### **SIDES**

• Carefully position the side panels snugly into place. Use the self-adhesive loop fastener to attach the side to the plastic trim. Cut the long length of loop fastener to match the hook fastener on the reverse of the liner. *The left photo indicates the loop fastener placement.* 

P.S. don't forget to remove any Silicone

# **OPTIONAL EXTRAS**

Photos are non-specific to this vehicle

# TAILGATE COVER (Non facelift version only)

• Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



#### **BUMPER FLAP**


- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



### **SEAT FLAP**

• The Seat Flap is designed to be used in conjunction with the **Rear Plus** Option(s).

With the rear seats in the folded position the Seat Flap extends the coverage over **some** of the exposed section of the seat backs and the headrests



Should you require further protection see the "Floor Extension" below





# FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.



(This item cannot be added at a late date)



