

## SKODA OCTAVIA ESTATE 2013 - 2020

### FNO-No Variable Floor

Our ref: HO571 FNO

#### PACKING REQUIREMENTS

- BOOT LINER  
Minimum of 8 self-adhesive loop fastener tabs
- REAR DOOR COVER  
Minimum of 15 self-adhesive loop fastener tabs



#### PREPARATION

- Remove the load cover cassette and the Plastic Pocket panels. They can be replaced later.
- PLEASE NOTE: This boot liner is NOT suit vehicles with a False Floor.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

#### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.



**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not disturb during.

Please note some of these photos are non specific to your vehicle.

#### BASE

- Position the base snugly into place. Start at the tailgate end.
- The hook fastener welds will attach directly to the carpet.



## FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.



## NOTE: REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo' )**



## SIDES

- Remove the Plastic Pocket Panel.
- Pass the bound cutouts over the protruding hooks. These have been lengthened to leave the two interior lights exposed.
- Pass the bound slots over the Plastic Pocket Panel retainers, and fasten snugly into place.
- Carefully position the rest of the side panels snugly into place.
- The hook fastener welded to the reverse face of the sides will attach directly to the carpet panels.

## FREQUENT USE KIT

If you intend to frequently remove/fit the boot liner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent use fitting kit” – ask our sales team or see our on-line “factory shop”.



## BACK

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



# OPTIONAL EXTRAS

Please note this photo is non-specific to your vehicle

## TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



## BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



## SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over raised headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

