

Renault Clio 5Door

2012 to 2019

Our ref: H0576

Packing requirements

BOOT LINER

- Minimum of 6 self-adhesive loop fastener tabs

REAR DOOR COVER

- Minimum of 18 self-adhesive loop fastener tabs



PREPARATION

- Remove the parcel shelf. It can be replaced later.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.



VERY IMPORTANT PREPARATION - Plastic/metal trim

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle plastic/metal trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any loop fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

BASE

- Position the base snugly into place.
- The hook fastener welds will attach directly to the carpet.
- Fasten the two ties to the chrome "D" rings located behind the seats.



Please note photos are non specific to your vehicle.

FITTING FRONT

- Align straps to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fastener will attach directly to the carpet.



NOTE: REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo')**

SIDES

- Carefully position the side panels snugly into place.
- The hook fastener welded to the reverse face of the sides will attach directly to the carpeted section of the panels.



BACK

- Carefully position the back panel snugly into place.
- Use the self-adhesive loop fastener tabs to attach only the section that covers the plastic trim.



Optional extras

TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



FREQUENT USE KIT

If you intend to frequently remove/fit the boot liner from/to your vehicle please note that the carpet may “fluff” up – we have an alternative “Frequent use fitting kit” – ask our sales team or see our on-line “factory shop”.



Please note the following photos are non-specific to your vehicle

BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the Rear Plus Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.





BEFORE APPLYING THE
SELF-ADHESIVE LOOP FASTENER TO
PLASTIC

YOU MUST FOLLOW
OUR CLEANING PROCEDURE

SEE **VERY IMPORTANT PREPARATION:** PAGE 1

