

RENAULT CAPTUR 2013 - 2019

Our ref: H0577RAISED & H0577LOW

Rear Seats must be slid as far back to the tailgate



- Packing requirements
- BOOT LINER**
 - Minimum of 6 self-adhesive loop fastener tabs
 - 1750mm of 20mm wide self-adhesive loop fastener
 - REAR DOOR COVER**
Minimum of 14 self-adhesive loop fastener tabs



VERY IMPORTANT PREPARATION



To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any loop fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately, we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 72hrs to reach full adhesion – do not disturb during.

PREPARATION

- Remove the parcel shelf. It may be replaced later.
- Ensure the false floor is positioned to suit your order, and the rear seats are slid as far back to the tailgate
- Unfold the Hatchbag and place in the vehicle. The panel with the Hatchbag label will sit against the back of the rear seat.

Please note not all the photographs are specific to your vehicle

BASE

- Position the base snugly into place. Start at the tailgate end.
- The hook fastener welded to the reverse face of the liner will attach directly to the carpet panels.



FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fastener welded to the reverse face of the liner will attach directly to the carpet panels.



REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo')**



BEFORE APPLYING THE SELF-ADHESIVE HOOK & LOOP FASTENER YOU MUST FOLLOW OUR CLEANING PROCEDURE SEE **VERY IMPORTANT PREPARATION**



SIDES

- Carefully position the side panels snugly into place.
- Use the 6 self-adhesive loop fastener tabs to attach the tailgate end of the sides to the plastic.
- Use the long length of self-adhesive loop fastener to attach the top edges to the plastic. Please cut to length, to fit between the numerous features: see above photos and refer to **REAR PLUS**



BACK

- Use the remaining long length of self-adhesive loop fastener tabs to attach the back panel to the tailgate plate. Trim to fit



Optional extras

Please note not all of the photographs are specific to your vehicle

BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



BEFORE APPLYING THE SELF-ADHESIVE LOOP FASTENER, YOU MUST FOLLOW OUR CLEANING PROCEDURE SEE **VERY IMPORTANT PREPARATION**