

MINI Mk III Hatch (3dr ONLY)

2014 to 2024

Our ref: H0589-FOUT

FALSE FLOOR REMOVED

Packing requirements

- BOOTLINER
Minimum of 6 self-adhesive loop fastener tabs
- REAR DOOR COVER
Minimum of 15 self-adhesive loop fastener tabs



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



PREPARATION

- Please ensure that the Rear seat backs are positioned to suit your order – UPRIGHT or RECLINED

“UPRIGHT”

REAR SEATS ARE MOST UPRIGHT



“RECLINED”

REAR SEATS ARE MOST RECLINED



- Remove the load cover. It may be replaced later.

Please note not all of the photographs are specific to your vehicle

BASE

- If you have a false floor – please remove it, it cannot be replaced once the Bootliner is fitted.
- Unfold the Hatchbag and place in the vehicle. The panel with the Hatchbag label sits against the back of the rear seat.
- Position the base of the Bootliner snugly into place.
- The hook fasteners welded to the reverse face of the base will attach directly to the carpet.



FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS**

(Please refer to REAR PLUS options on website to see detailed photos)



SIDES

- Carefully position the side panels snugly into place.
- The hook fasteners welded to the reverse face of the liner will attach directly to the carpet panels.



BACK

- Carefully position the back panel snugly into place.
- Use the pre-cut loop fastener tabs to attach the back panel to the tailgate plastic trim.



Please note these photos are non-specific to your car.

OPTIONAL EXTRAS

SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the Rear Plus / Split options. With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts



BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

