

FITTING INSTRUCTIONS hatchbag.co.uk

SKODA FABIA ESTATE - 2015 on

Our ref: H0603

PACKAGING REQUIREMENTS.

BOOT LINER

- **27 x tabs** self-adhesive loop fastener
- 280+290+300+330mm x 20mm wide self-adhesive loop fastener
- REAR DOOR COVER
- 20 x tabs self-adhesive loop fastener





VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.**

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.





STEP I. PREPERATIONS

- Remove the load cover. It may be replaced later.
- Remove the plastic side panels from both sides, they will be replaced later (image A)

Please note not all of the photographs are specific to your vehicle

STEP 2. FITTING BASE

• Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges.

STEP 3. FITTING THE FRONT

- - PLUS / SPLIT VERSION ONLY fasten the hook & loop fastener between the side panel and the seat panel. (image C)
- Loop the hook & loop fastener straps around both headrest posts. (image D). Makes sure to hold the front part of the base in position as not to pull the Hatchbag too far up. Repeat the other headrest.

REAR PLUS VERSIONS

You MUST unfasten the hook & loop fastener + the headrest straps before you recline the rear seat uppers.









STEP 4. FITTING THE SIDES

Ì٦

Align the front end of boot liner sides to the boot sides. Attach the 290mm self adhesive loop fastener strip to the nearside in line with the hook fastener sewn onto the boot liner as show in image E.

Repeat the steps with the offside front using the 280mm long loop fastener strip shown in image E.

Attach the boot liner around the pocket corner using 3 (nearside) and 2 (offside) loop fastener tabs shown in **image F**. Attach the loop fastener tabs in line with the tabs sewn onto the boot liner.

Attach the 330mm self adhesive loop fastener strip (nearside) and 300mm strip (offside) behind the plastic panel slots shown in image G.

Insert the boot liner pockets into the boot recess. Attaching the hook fastener strip on the underside of the pocket to the previously attached loop fastener strip. (Image G)

Attach 3 self adhesive loop fastener tabs inside the recess in line with the hook fastener sewn onto the boot liner. There are 2 loop fastener tabs on the recess ceiling and 1 on the side shown in image H.







STEP 4. FITTING THE BACK

	•
€	
	ሽ
	U

Attach the rear end of the bootliner to the boot using self adhesive loop fastener tabs. Align the loop fastener strips to the hook fastener sewn onto the boot liner.

- 2 tabs on both sides of the boot (image I)
- 4 tabs on both sides of the bottom ridged panel (image J)
- 1 strip on the front side of the back panel, located in the centre of the back, this is indicated by the arrow. (image J)





STEP 4. FITTING SIDE PANELS

- Insert the plastic side panels removed in STEP 1.
- Attach the side with a little notch (indicated by the arrow) to the front of the boot liner. Wrap the pvc panel around the plastic panel and attach it to the hook fastener sewn on the other side. (image K)



Tuck the little flap under the rear sides of the boot liner and attach it using a self adhesive loop fastener tab. (image L)







OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)
 - Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 5C. BUMPER FLAP

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. Ensure you do not cut through the stitching
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound











OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5D. FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION AS YOU PLACE YOUR ORDER (*The Seat Flap 5A*, *The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date*)

