

## MINI CLUBMAN - 2015 on

## 4 OPTIONS - (Raised/Low - Upright/reclined)

Our ref: H0612

### PACKAGING REQUIREMENTS.

#### **BOOT LINER**

<mark>6 x tabs</mark> self-adhesive loop fastener

#### TAILGATE COVER

26 x tabs self-adhesive loop fastener



Photo: Raised-Upright Split seat version



Photo: Low-Reclined Split seat version

#### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.** 

**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not touch during.





#### **STEP I. PREPERATIONS**

• Remove the load cover. It may be replaced later. (image A)

#### RAISED FLOOR + UPRIGHT SEATS

- Please make sure the false floor is inserted (image B)
- Please incline your seats to the upright position as shown in image E

#### RAISED FLOOR + RECLINED SEATS

- Please make sure the false floor is inserted (image B)
- Please recline your seats to the reclined position as shown in image D

#### LOWERED FLOOR + UPRIGHT SEATS

- Please remove and store the false floor (image C). It cannot be replaced later.
- Please incline your seats to the upright position as shown in image E

#### LOWERED FLOOR + RECLINED SEATS

- Please remove and store the false floor (image C). It cannot be replaced later.
- Please recline your seats to the reclined position as shown in image D











#### **STEP 2.** FITTING BASE

• Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. (Image F)

#### LOWERED FLOOR OPTION ONLY

• Push the lowered floor section of the boot liner into the lowered floor compartment of the boot and push it snuggly into the corners. (Image G)





#### **STEP 3.** FITTING THE FRONT

- - PLUS / SPLIT VERSION ONLY fasten the hook & loop fastener between the side panel and the seat panel. (image H)
- Starting with the middle headrest loop the hook & loop fastener straps around both headrest posts. (image I). Make sure to hold the front part of the base in position as not to pull the Hatchbag too far up. Repeat the procedure with the left and right seat.

#### **REAR PLUS VERSIONS**

You MUST unfasten the hook & loop fastener + the headrest straps before you recline the rear seat uppers. *('Please refer to REAR PLUS options on website to see detailed photo')* 



#### **STEP 4.** FITTING THE SIDES

- Position the sides of the boot liner into place. Firmly press the sides to securely fasten the hook fastener to the carpet. (image J)
- Fasten the boot liner flap on the top edge of the boot liner to the carpeted ledge on both sides of the boot Firmly press to securely fasten the hook fastener to the carpet. (image K)



Attach the boot liner to the rear plastic lip using the self-adhesive loop fastener provided by lining up the hook fastener on the boot liner to the correct position. These areas are shown in image L & image M

#### **RECLINED OPTION ONLY**

• Tie the 2 straps located at the front of the sides around the metal loop on the recline mechanism. (image N)



Photo: Low-Reclined Split seat version



## **OPTIONAL EXTRAS**

Please note the following photos are non-specific to your vehicle

#### STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

#### **STEP 5B.** TAILGATE COVER

• Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)



Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

#### STEP 5C. BUMPER FLAP

- Fit the Boot liner first
- Close the nearside door and open the offside .
- Attach the smaller section of the bumper flap to the loop fastener on the base of the Boot liner; ensure the inner edge of the flap aligns to the nearside door (arrow in photo 5)
- Open the nearside door and fit the larger section: it is designed to overlap the smaller section.
- The nearside section can remain folded into the vehicle when just the offside door is open. Both flaps can be detached and stored elsewhere when you close the tailgate doors.













# **OPTIONAL EXTRAS** page 2

Please note the following photos are non-specific to your vehicle

#### **STEP 5D.** FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION AS YOU PLACE YOUR ORDER

IMPORTANT NOTE:

The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date

#### STEP 5E. FREQUENT USE KIT

• If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent Use Fitting Kit"

The Frequent Use Kit is available to buy from our "online" Factory Shop – simply add it to your order from the Factory Shop. These can also be ordered at a later date.





