

FITTING INSTRUCTIONS hatchbag.co.uk

VOLVO XC90 - 2015 on

3RD ROW FOLDED DOWN

Our ref: H0618-RW3FLD

PACKAGING REQUIREMENTS. BOOT LINER

- 10x tabs self-adhesive loop fastener
- 2x ref. 121 tabs (plastic / loop fastener)
- 4x ref 124 at 160mm length
- 2x 680mm + 2x 150mm 20mm selfadhesive loop fastener
- 2x 200mm 30mm self-adhesive loop fastener

REAR DOOR COVER

• 27x tabs self-adhesive loop fastener





REF:121



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any Hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The Hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.**

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.



STEP I. PREPERATIONS

- Remove the load cover. It may be replaced later.
- Please tilt the 2nd row seats to the most upright position. (image A)

Please note not all of the photographs are specific to your vehicle

STEP 2. FITTING BASE

- Line up 2x ref:124 to the chrome strip on both sides of the boot (total 4). (image B)
- Lift up the false floor and attach the ref:124 to the inside plastic surface next to the chrome strip using 2 self adhesive loop fastener tabs for each ref:124 (total 8). (image C+D)
- Attach the hook fastener portion of the ref:124 to previously attached loop fastener tabs. Then lower the false floor with the loop portion protruding out. (image E)
- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges.
- Fasten the 2 ties sewn into front of the base to the folded 3rd row seats' headrest posts to secure the liner. (image F)
- Pull the base taut from the rear and secure it to the ref:124 sticking out from the false floor. (image G)
- Attach the ref:121 clips to both sides of the boot door opening. To do this pull back the rubber edge and push the plastic section of the clip behind the boot panel (image H). Slide the clip down to the same level as the hook fastener weld on the boot liner. (image I)



















STEP 3. FITTING THE FRONT

- PLUS / SPLIT VERSION ONLY fasten the hook & loop fastener between the side panel and the front panel. (image J)
- For the left and right headrest: Pass the elastic loop fastener straps through the middle of the headrest and around to fasten them to the hook fastener patch on the front panel of the boot liner. (image K)
- For the middle headrest: Loop the hook & loop fastener straps around both headrest posts. (image L). Makes sure to hold the front part of the base in position as not to pull the Hatchbag too far up.

REAR PLUS VERSIONS

You MUST unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. ('Please refer to REAR PLUS options on website to see detailed photo')





STEP 4 FITTING THE SIDES

- Stick the long lengths of self adhesive loop fastener strips onto the plastic above the top edge of the carpet (image M) to which the side of the boot liner will attach.
- As shown in (image N), use the 20mm self adhesive loop fastener on the green highlighted areas with the longer 680mm strip on the tailgate end and the 150mm strip at the seat end. Use the 30mm loop fastener strip on the area indicated by the yellow line on (image N).



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is a 3 piece attachment designed to protect the top of your rear seat giving additional protection from drooling dogs etc. (the images in this document are single piece seat flaps different from your order)
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Attach the 3 section Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. (image 1)
- The outer flaps are then placed over the rear head rests and down the back of the passenger seats. The middle headrest sits between the headrests to allow you to see through the rear window. (image 2)

STEP 5B. TAILGATE COVER

• Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)



Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 5C. BUMPER FLAP

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. Ensure you do not cut through the stitching
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5D. FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors

PLEASE REQUEST FURTHER INFORMATION AS YOU PLACE YOUR ORDER

(The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date)

