

FITTING INSTRUCTIONS hatchbag.co.uk

KIA SORENTO - 2015 Onwards

7 SEATER ONLY (ROW 3 FOLDED)

Our ref: H0629-SE7

PACKAGING REQUIREMENTS. BOOTLINER

- 2x Ref:135
- 2x 890mm 30mm wide selfadhesive loop fastener
- 2x 280mm 30mm wide selfadhesive loop fastener
- **2x 360mm** 30mm wide selfadhesive loop fastener
- 8x tabs self-adhesive loop fastener
- 2x 80mm 20mm wide sew-on loop fastener
- TAILGATE COVER
- <u>26 x tabs</u> self-adhesive loop fastener



Load cover out version - Rear plus with seat split boot liner Inc. seat & bumper flap preparation



REF.135 FASTENER



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.**

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.





STEP I. PREPARATIONS

- Remove the load cover. It may be replaced later
- Fold the 3rd row seats, they are not usable with the liner fitted.
- Slide the 2nd row seats as far back as they will go.
- Set the 2nd row seat recline so that the seat backs are 4cm away from the load cover slots as seen in image A.
- Hook the 3rd row seatbelt behind the clip. Push the seatbelt strap so it sits flush against the side panel and stick the ref.135 fastener over it (image B) with the self-adhesive hook fastener parts attaching to the side panels as shown in image C.







STEP 2. FITTING BASE

• Place the bootliner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The fasteners welded to the reverse fixes directly to the carpet. (image D)



STEP 3. FITTING THE FRONT

- - PLUS / SPLIT VERSION ONLY fasten the hook & loop fastener between the side panels and seat panel. (image E)
- Starting with the middle headrest, loop the hook & loop fastner straps around both headrest posts. (image F). Make sure to hold the front part of the base in position as not to pull the Hatchbag too far up. Repeat the procedure with the left and right headrests.

REAR PLUS VERSIONS

You MUST unfasten the hook & loop fastner + the headrest straps before you recline the rear seat uppers. ('Please refer to REAR PLUS / SPLIT options on website to see detailed photo')





STEP 4. FITTING THE SIDES AND BACK

- Attach the 4 appropriate lengths loop fastener strips and the self-adhesive fastener tabs onto the side panels as shown in the following steps.
- The 360mm long self-adhesive loop fastener strips go on the window sills (image H) on both sides of the boot.
- The 280mm lengths of self adhesive loop fastener go behind the 3rd row seatbelts on both sides of the boot (highlighted in blue - image I). Attach the 80mm long non-adhesive loop fastener over the portion of the hook fastener sewn onto the boot liner that sits over the seatbelt to stop the hook fastener from scratching it. (highlighted in orange - image I)
- Attach 4 self-adhesive loop fastener tabs on both sides of the boot in line with the hook fasteners welded onto the boot liner sides. (highlighted in green Image J)
- Stick the 890mm long self adhesive loop fastener strips along the tailgate opening from the lock in the center up the sides. (image K) Snip the fastener strip to help ease it around the bend.
- Fasten the boot liner to these fasteners using the hook fastener welded & sewn to the back of it.



STEP 4. FITTING THE SIDES AND BACK CONT.....

• The load cover can now be relocated into the two appropriate holes (image L)



Should it be necessary to relocate your load cover to the secondary locating position you may cut another set of holes as the fabric does not tear / fray. Please make sure not to cut through the tape as it may come undone. You can refer to our online guide for cutting openings into the boot liner at ;

http://www.hatchbag.co.uk/blog/cutting-openings-intoboot-liner/

(image M)



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP (& TAILORED)

- The Tailored Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc. (image 1)
- The Seat Flap is designed only to be used in conjunction with the **Rear Plus/Split**. With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower the headrests
- Attach the Seat Flap / Tailored Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. (image 2)







OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5B. TAILGATE COVER

Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive fastener tabs will be stuck. (image 3)

• Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 5C. BUMPER FLAP

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 4)
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. Ensure you do not cut through the stitching
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.

STEP 5D. FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors

(The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date)





