

## NISSAN X-TRAIL - 2014 - 2022

7 SEATER (3RD ROW FOLDED & NOT USABLE)

OUR REF: H0644

### PACKAGING REQUIREMENTS.

#### BOOT LINER

- **2x 520 mm** 30mm wide self-adhesive loop fastener
- **370mm + 300mm + 200mm + 170mm** 30mm wide self-adhesive loop fastener
- **13x tabs** self-adhesive loop fastener

#### TAILGATE COVER

- **24 x tabs** self-adhesive loop fastener



split liner with seatflap and bumper flap prep



### VERY IMPORTANT PREPARATION



To ensure the self-adhesive loop fastener sticks to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICON** applied during manufacture and valeting.

#### To do this please:

1. Use a silicon remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a **separate** clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 loop fastener tab to see if it sticks. (Repeat step 1 to 2 if it doesn't stick)
3. Attach the loop fastener and let them fully adhere over the next 24 hours for the best bond.

*\*The loop fastener cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



## STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Slide the 2nd row seats as far back as possible towards the tailgate end.
- Please recline your seat so that it is 100 mm away from the load cover cassette socket as shown in **image A**.



## STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fastener welded to the reverse face fix directly to the carpet. (**image B**)



## STEP 3. FITTING THE FRONT


- **- PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fastener between the side panels and the seat panel. (**image C**)
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts. (**image D**). Make sure to hold the front part of the base in position as not to pull the Hatchbag too far up. Repeat the procedure with the left and right headrests.





### REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. (*Please refer to REAR PLUS / SPLIT options on website to see detailed photo*)



## STEP 4. FITTING THE SIDES

-  Attach the 520 mm long self-adhesive loop fastener strips along both sides of the tailgate opening of the car, starting from the top joint in the plastic going downwards along the rubber seal (highlighted in green in image E & G). Snip to aid application.


### NEARSIDE

-  Attach the 300mm & 200mm long loop fastener strips to the nearside of the boot below the joint in the plastic. (Image E)
-  Attach 3 self-adhesive loop fastener tabs, 1 on the base in the recess, and 2 on either side of the storage compartment on the armrest in line with the hook fastener welded onto the boot liner. (Image E)
- Fasten the hook fastener sewn onto the top edge of the boot liner to the previously attached loop fastener. The seatbelt strap sits underneath the liner with the metal prong clipped into the seatbelt tidy. (Image F)

### OFFSIDE

-  Attach the 370mm & 170mm long loop fastener strips to the offside of the boot below the joint in the plastic as previously done on the nearside. (Image G, ref image E)
-  Attach 3 self-adhesive loop fastener tabs, 1 on the base in the recess, and 2 on either side of the storage compartment on the armrest in line with the hook fastener welded onto the boot liner. (Image G, ref image E)
- Attach the front end of the boot liner side to the previously applied loop fastener pushing the top lip under the seatbelt (image G) and then attach the rear end. The lower half of the seatbelt strap sits under the boot liner with the top half exposed and clipped into the seatbelt tidy. (image G & H)

### BACK

-  Attach 3 self-adhesive loop fastener tabs onto the ridged plastic panel on either side of the tailgate lock, in line with the hook fastener welded onto the boot liner. Attach 1 tab in the middle behind the lock. (Image I)



# OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

## STEP 5A. SEAT FLAP (+TAILORED)

- The **Tailored** Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc. (image 1)
- The Seat Flap is designed **only** to be used in conjunction with the **Rear Plus/Split**. With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. (image 2)



## STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 3)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



## STEP 5C. BUMPER FLAP

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 4)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



## OPTIONAL EXTRAS page 2

*Please note the following photos are non-specific to your vehicle*

### STEP 5D. FLOOR EXTENSION

The “Floor extension” offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm.
- It will offer no protection to the rear doors

*The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date*

