

PACKAGING REQUIREMENTS.

BOOTLINER

- **4x 500 mm** 30mm wide self-adhesive loop fastener
- **2x 380 mm** 30mm wide self-adhesive loop fastener
- **1x tabs** self-adhesive loop fastener

WINDOW SILL FLAPS

- **2x 280 mm** 30mm wide self-adhesive loop fastener
- **2 x tabs** self-adhesive loop fastener

TAILGATE COVER

- **26 x tabs** self-adhesive loop fastener

RENAULT MEGANE SPORTS TOURER - 2016 on

FALSE FLOOR IN RAISED POSITION

OUR REF: H0659



Split boot liner with Sill Flaps, Seat Flap and Bumper Flap prep



VERY IMPORTANT PREPARATION



To ensure the self-adhesive loop fastener sticks to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 loop fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary)
3. Attach the hook & loop fastener and let them fully adhere over the next 24 hours for the best bond.



**The hook & loop fastener cannot be used once it has been in contact with silicone. Replacement kits are*

STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later. *(not with windowsill flaps installed)*
- Set the false floor to its raised position. *(image A)*



STEP 2. FITTING THE BASE

- Place the bootliner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fastener welded to the reverse face fix directly to the carpet. *(image C)*



STEP 3. FITTING THE FRONT

- **- PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fastener between the side panels and the seat panel. *(image D)*
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts. *(image E)*. Make sure to hold the front part of the base in position as not to pull the bootliner too far up. Repeat the procedure with the left and right headrests.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fastener + the headrest straps before you recline the rear seat uppers. *(Please refer to REAR PLUS / SPLIT options on website to see detailed photo)*

STEP 4. FITTING THE SIDES & BACK

- Attach the hook fastener welded onto the rear sides of the bootliner directly to the carpet (orange arrow) and position the recess into place. (Image F & G)



Line up the hook fastener sewn onto the top of the bootliner sides to the boot. Cut the 500mm long self-adhesive loop fastener strips to size and stick them onto the boot sides in line with the hook fastener on the bootliner (yellow). (Image F)



Stick the 380mm long self-adhesive loop fastener onto the plastic panel located on both sides of the lock at the tailgate end of the boot. (Image H)



Stick 1 self-adhesive loop fastener tab on the center inside of the back panel in line with the hook fastener welded onto the back panel of the bootliner. (arrow - Image H)

- Fasten the bootliner to it using the hook fastener welded onto it. (Image H)

2 additional lengths of the 500mm loop fastener have been provided incase you need to re-align the hook & loop fastener.

WINDOW SILL FLAPS

- Unfasten the top of the boot liner from the boot sides, as the window sill flaps are attached underneath.



Attach the 280mm long self-adhesive loop fastener on the window sill along the window. (Image I)

- Align the front end of the sill flaps with the angle on the side panel (Image J). Attach the smaller section of the sill flap to the loop fastener placed in the previous step (Image I). The lower section of the flap attaches to the loop fastener placed in image F.



- Attach 1 self adhesive loop fastener tab as highlighted by the arrow in image J
- Re-attach the bootliner onto the windowsill flaps.



The loadcover cannot be used when the windowsill flaps are installed.

OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Bootliner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)



Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 5C. BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the bootliner. (image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5D. FLOOR EXTENSION

The “Floor extension” offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.(image 6)

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors



The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date

STEP 5E. FREQUENT USE KIT

- If you frequently remove/fit your Bootliner from/to your vehicle please note that the carpet will “fluff” up – we have an alternative “Frequent Use Fitting Kit” (image 7+8)

The Frequent Use Kit is available to buy from our “on-line” Factory Shop – simply add it to your order from the Factory Shop. These can also be ordered at a later date.

