

## Jeep Renegade – 2015 on

Shape 2 – False Floor Removed & False Floor Raised  
our ref: H0668-SH2-FOUT / SH2-FRSD

### Packaging requirements:

- BOOT LINER**
  - **1x 1530mm** 30mm wide self-adhesive loop fastener
  - **8x tabs** self-adhesive loop fastener
- TAILGATE COVER**
  - **22 x tabs** self-adhesive loop fastener



**FOUT VERSION** – Split boot liner prepped for a seat flap and bumper flap and Extension



### VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

#### To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

*\*The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



## STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.



**FOUT VERSION** (False Floor Removed)  
Remove the variable false floor, and store it, it cannot be used with this boot liner.

**FRSD VERSION** (False Floor Raised)  
Raise the variable false floor to the highest level.



## STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. (image A)



## STEP 3. FITTING THE FRONT

- PLUS / SPLIT VERSION ONLY - fasten the hook & loop fasteners between the side panels and the seat panel. (image B)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (image C). Make sure to hold the front part of the base in position as not to pull the boot liner too far up. Repeat the procedure with the left and right headrests.



## REAR PLUS VERSIONS

You MUST unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. (Please refer to REAR PLUS / SPLIT options on website to see detailed photo)

## STEP 4A. FITTING THE SIDES CONTINUED

- Raise the sides up to see where the hook fastener sewn and welded onto the boot liner aligns to the boot walls
- Using the long 30mm wide loop fastener strip, cut off 3 appropriate lengths to stick onto the boot in the areas highlighted in blue in **image D and E**.
- Attach 5 loop fastener tabs to the areas highlighted in yellow in **image D and E**.



## STEP 4B. FITTING THE BACK

- Cut a further 2 lengths from the 30mm wide loop fastener strip, and fasten them on the rear sides going along the rubber seal. (highlighted in green, **image F and G**). The cut length should be long enough to attach the top 3 vertical fastener tabs welded onto each side of the boot liner.
- Cut 2 more lengths from the 30mm wide loop fastener strip, and stick them on the rear ridged panel going on both sides from the central lock to the d-ring slot. (highlighted in pink, **image I**)
- Attach 1 self adhesive tab, on each side of the boot, in the corner between the 2 previously attached loop fastener strips and inline with the hook fastener tab welded onto the boot liner. (yellow circle, **image F, G and H**)



### **FOOT VERSION** (False Floor Removed)

Attach the final self adhesive tab on in the center of the back panel as shown with the white arrow in **image H**.

- Fasten the boot liner to the previously attached fasteners using the hook fastener welded / sewn onto the reverse side of the Bootliner.



# OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

## STEP 5A. SEAT FLAP (+TAILORED)

- The **Tailored** Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc. (image 1)
- Lower the headrests
- Attach the Tailored Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats.
- The additional Seat Flap is designed **only** to be used in conjunction with the **Rear Plus/Split**. With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests. (image 2)



## STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 3)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



## STEP 5C. BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 4)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



# OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

## STEP 5D. FLOOR EXTENSION

The 'Floor extension' offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 6)

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors



The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date

## STEP 5E. FREQUENT USE KIT

- If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent Use Fitting Kit" (image 7+8)

The Frequent Use Kit is available to buy from our "on-line" Factory Shop – simply add it to your order from the Factory Shop. These can also be ordered at a later date.

